


## Micrometer Heads

Components commonly used for checking the various displacements on measuring fixtures, coordinate tables, microscopes, machines as well as other special appliances. Mounted on the cylindrical clamping shaft.



### Models MICROMASTER®


Without spindle lock.



60.30040




60.30038/39



No	mm	mm
60.30038	0 ÷ 30	12h6
60.30039	30 ÷ 0	12h6
60.30040	0 ÷ 30	12h6

### Model ISOMASTER® AR

Without spindle lock



No	mm	mm	No	in	mm
02.11201	0 ÷ 25	12h6	02.21201	0 ÷ 1	12h6

